



Own the best looking house on the block.

Exterior Painting Procedures



Step 1: Washing. All of the areas that will be painted within your scope of work will be thoroughly washed. This will remove all mildew, algae dirt and salt deposits.



Step 2: Tarping. All of the surfaces and landscaping to be worked around will be protected with canvas and plastic tarps. Additionally, tape will be used to protect any areas where tarps would be impractical.



Step 3: Scraping. Failing paint must be removed. Any loose, flaking and/or peeling paint will be thoroughly hand scraped prior to painting. Cedar wood siding flaking will be wire brushed prior to re-staining.



Step 4: Priming. Priming bare wood and metal will be done with appropriate primers. Horizontal areas where water may sit creating rusting areas will be given two coats of primer.



Step 5: Caulking. Joints and seams allowing exterior moisture entry will be caulked anywhere that wood meets wood.



Step 6: Removal. Downspouts and address numbers will be removed by the team where applicable.



Step 7: Painting! Thorough prep work will be done before the paint is applied. We will paint using the best quality paints and applicators.



Step 8: Daily Cleaning. On multi-day jobs, we make sure to pack-up and pick up at the end of the day.



Step 9: Final Inspection. Before the crew packs up their equipment, we do a final walk-around to ensure all contracted areas are painted properly.



Step 10: Review. At the end of each job, we ask our customers to complete an online review to ensure that all work has been performed to meet or exceed your standards.

Visit our website at www.colorworldpainting.com to see more painting procedures for interior, exterior, power washing, and other painting projects!